



Upgrade Guide for Smart HVR and IPL cameras


- 1.- Access the HVR or IPC through Internet Explorer.
- 2.- Enter username and password (by default "admin" / "siera").
- 3.- Go to "Device Cfg".



- 4.- Go to "Advanced" - "Upgrade".



- 5.- Press "Browse", in the search window select the firmware file.



- 6.- Press the "Upgrade" button to start the HVR update process.
- 7.- Once finished, the HVR will reboot and the update process is complete.

Important: Never turn off the PC, the HVR or IPC when the update is being sent, as this could make the equipment unusable.

Once the update is finished, run the "Restore" program.

Run "Restore" as administrator, enter the IP address of the HVR and click the "Restore" box. Press the button "Ping", if the message indicates that the ping is done, press "Search" and then "OK".

Finally restart or turn off and on your HVR.

This process will change all the HVR parameters to the default values.