

Take a screenshot or a video clip of a recording using the VMS Software

Quick Help



1° Enter the VMS software.



2° Go into settings to select the recording paths and formats.

VMS Siera	Sew Tab				010 1 <mark>0</mark> 2	× 15:38:57
Operation Live View	Event					
Search Playback	E-Map	Log				
Configuration	User	Oevices	Tour & Task	Event CFG	Record Plan	



3° Select "Record Store".

	System Config	×
Basic Config	Basic Config Initial Page: New page	
Alarm Setting	Start With The OS	
Device Manager	Auto Login Start Time Record	
System And Language	Restore The Preview First Load in Display	
Record Store	Instantly replay time: 15Minutes 💌	
Logs Config	Alarm Setting Image: Constraint of the set	
Buckup/Restore	Pop Emap Dialog Accept Non-deployed Alarm	
	V Show Floating Window	
	Alarm Type: Motion Sound File Path: C./Program Files/Siera VMS/vms/sound/else/alarm sensor.wav	Φ
	Device Manager	-
	Port: 3333	
	Apply Save	Cancel

4° In this section you can configure the storage parameters.

	System Config	×	
Basic Config	Record Store Picture Path: C /Program Files/Siera VI	NSAms/Organication/Picture	
Alarm Selling	Manual Recording Path: C /Program Files/Siera V	MS/vms/Organization/HandleRecord	Path where the backups will be stored.
Device Manager	Device Recording Path: C/Program Files/Siera VI Time/Alarm Recording Path: JProgram Files/Siera VIII	MSAms/Organization/RemoteRecord 🔋	Video format.
System And Language	Snap Picture Type: Super Storage File: H25X MP4 AN		
Record Store	Min Limit Space(GB): 99		
Logs Config	Handle Pack Interval(Minute): 5	Ī	
Buckup/Restore	Cover Video File Logs Config Aiarm Logs Storage Time: 7: + System	n Logs Storage Time: 7	
	Buckup Restore Backup Restore		
		Appy Save Cancel	



5° After making the settings, press "Apply" and then "Save".

		System C	onfig	×
Basic Config	Record Store	C./Progra	m Files/Siera VMS/vms/Organization/Picture	
Alarm Setting	Manual Recording Path:	C:/Progra	m Files/Siera VMS/vms/Organization/HandleRecord	
Device Manager	Device Recording Path: Time/Aarm Recording Path:	C:/Progra :/Program	m Files/Siera VMS/vms/Organization/RemoteRecord Files/Siera VMS/vms/Organization/BackupRecordPath	
System And Language	Snap Picture Type: Record Storage File:	 JPEG H26X 	BMP MP4 AVI	
Record Store	Min Limit Space(GB):	99 🔹		
Logs Config	Handle Pack Interval(Minute): Time Pack Interval(Minute):	5		
Buckup/Restore	Cover Video File Logs Config Alarm Logs Storage Time:		System Logs Storage Time: 7	÷
	Buckup/Restore Backup Res	tore		
			Apply Save	Cancel

6th Enter "Playback".

VMS Siera	New Tab	±			000 100	- 🗆 X 15:31:37
Operation						
۲						
Live View	Event					
Search						
	Ŧ					
Playback	E-Map	Log				
Configuration						
X	2	0	0		3	
Devide CFG	User	Devices	Tour & Task	Event CFG	Record Plan	



7° Select the camera, date and time of the playback, and in the same view you can take an image capture or a video clip as shown below.



8° The following window will appear where you can select the videos to download.

cord Source: Rem	14 00 00 00 2022 04 14 22 50	50	Owner Channel TEST
ID ID	File	Size	Type
1	16:19:3616:20:03	2457	11 .8,



9° Select the video or videos to download and press "Down Seleted"

	Seach F	Results	>
Record Source. Rem Query Time: 2023.04	iole Device .14 00:00:00-2023.04.14 23:59	:59	Query Channel: TEST:1
ID ID	File	Size	Туре
☑ 1	16:19:3616:20:03	2457	11 .♣
•			

10° A window will appear indicating the status of the downloads.

All Start Time Finsh Time Size(KB) Status Operation TEST:1 2023.4.14 16:19.36 2023.4.14 16:20.3 2457 59.956 II III
Pause Start Delete All Start Time Finsh Time Size(KB) Status Operation TEST:1 2023.4.14 16:19:36 2023.4.14 16:20:3 2457 199.976 II III
All Start Time Finsh Time Size(KB) Status Operation TEST.1 2023.4.14 16.19.36 2023.4.14 16.20.3 2457 99.99 11 11
TEST:1 2023.4.14 2023.4.14 2457 99.9%



11° Once the downloads are finished, you will be able to access the folder on the PC to be able to view or operate with them.







sieraelectronics.com